


How to Install OMNIBUS F4 Flight Controller USB Driver

1. Keep the drone powered off, don't plug the battery. Plug in the USB cable to a computer.
2. Open Zadig, if your drone is recognized properly, it should be like this:



If your drone is not recognized, please tick "Options"→"List All Devices",




Then choose "OmnibusF4"

3. Choose "USB Serial (CDC)"



4. Click "replace driver", wait for driver installation.



5. When driver is installed properly, unplug then replug the USB cable.

Open Betaflight App and check the top right corner.

If you get "COMx", your drone is ready to connect to Betaflight.



If you don't get any "COMx" info, please get a better USB cable and double check the driver installation.

Some computers have very limited USB power output which making a failed USB connection, in this case, please have a try with main battery connected to your drone.